

SPECIFICATION FOR APPROVAL

C	ustomer :		
С	ustomer Part No:		
D	escription:	Thermal module	
J	ARO Model No:	JSC00150	REV: 0
S	ample Issue No:		
S	ample Issue Date :		
S	pecification Status:	V Preliminary	Formal
		PPY OF THIS SPECIFICATION OR PRODUCTION PRE-ARRA	
	APPROVED BY CU	JSTOMER:	
	DATE	:	



JARO Thermal USA office 4800 T-Rex Avenue Suite 265. Boca Raton, FL 33431

www.JAROthermal.com

Ph: 561-241-6700 Fx: 561-241-3328

Jaro Thermal Taiwan office Building H, No.119-1, Zhudong Rd., Renwu

Dist., Kaohsiung City, Taiwan 81448

www.jarothermal.com

Ph: +886-7-375-2053 Fx: +886-7-374-7403

PREPARED BY :	Franco Huang	DATE :	08/21/2025
CHECKED BY:	Chris Hsu	DATE :	08/21/2025
APPROVED BY :	Chris Hsu	DATE :	08/21/2025

We keep the world coolTM



JARO MODEL NUMBER


JSC00150


Revision of Spec History


Revision	Change Content	Change page	DATE	BY
0	Created SPEC		08/21/2025	Franco Huang


Notice:


- 1. This specification will be changed based on Jaro Thermal 's notification. Please refer to update revision of spec by contacting Jaro Thermal.
- 2. This specification clarify all the mechanical & electrical characteristics of DC brushless fans & AC brushless fans & heat sink.
- 3. The specification of this product is described in detailed document. Please do not use the fan without proper usage. Please contact Jaro Thermal if you have special requirement which is not listed on this specification.
- 4. Any of change, please contact Jaro Thermal to change the new revision in order to make sure all technical data is up to date. Any ECN change will be followed by sending new update specification.
















SPECIFICATION FOR APPROVAL

Customer:			
Customer Part No:			
Description:	DC BRACKET		
JARO Model No:	JED0401012US1A0T((8P5AR)-X(2190) REV:	C
Sample Issue No:		_	
Sample Issue Date :			
Specification Status:	V Preliminary	Formal	
SIGNED APPROVAL FO	OPY OF THIS SPECIFICATION PRE-ARE		
APPROVED BY C	USTOMER:		
DATE			



JARO Thermal USA office 4800 T-Rex Avenue Suite 265. Boca Raton, FL 33431

www.JAROthermal.com

Ph: 561-241-6700 Fx: 561-241-3328

JARO Thermal Taiwan office Building H, No.119-1, Zhudong Rd., Renwu Dist., Kaohsiung City, Taiwan 81448

www.JAROthermal.com

Ph: +886-7-375-2053 Fx: +886-7-374-7403

PREPARED BY: Franco Huang		DATE :	01/10/2025
CHECKED BY:	Ivan Chen	DATE :	01/10/2025
APPROVED BY:	Jay Su	DATE :	01/10/2025

We keep the world coolTM



JARO SPEC NUMBER

SPEC

2190

Revision of Spec History

Revision	Change Content	Change page	DATE	BY
0	Created SPEC		01/10/2025	Franco Huang

Notice:

- 1. This specification will be changed base on JARO Thermal 's notification. Plesae refer to update revision of spec by contacting JARO Thermal.
- 2. This specification clarify all the mechanical & electrical characteristics of DC brushless fans & AC brushless fans & Heatsink.
- 3. The specification of this product is described in detailed document. Plesae do not use the fan without proper usage. Plesae contact JARO Thermal if you have special requirement which is not listed on this specification.
- 4. Any of change, Plesae contact JARO Thermal to change the new revision in order to make sure all technical data is up to date. Any ECN change will be followed by sending new update spec.



SPECIFICATION





JARO Model	: JED0401012US1A0T(8P5AR)-X(2190)
Samples attached	: pcs
Safety Approval	: CE
FEATURES	FG SIGNAL HIGH TEMP RATED IP-51 RATED RD SIGNAL V SINGLE PHASE V 4-POLE PWM THREE PHASE 8-POLE
DIMENSIONS	: Ф38 X 11.5 mm
BEARING TYPE	: SLEEVE BEARING
MOTOR PROTECTION	: BY IC
RATED VOLTAGE	: 12.0 VDC
OPERATING VOLTAGE RANGE	: 7.0 ~ 12.6 VDC
START - UP VOLTAGE	: 7.0 VDC, (POWER ON/OFF)
REAL CURRENT	: 0.18 Amp
REAL POWER	: 2.16 Watt
RATED CURRENT	: 0.25 Amp +10%MAX
RATED POWER	: 3.00 Watt
RATED SPEED	: 8000 RPM ± 10 %
	(IN FREE AIR AT RATED VOLTAGE)
AIR FLOW	: 7.80 CFM (min.: 7.020 CFM)
AIR FLOW	: 0.220 CMM (min.: 0.198 CMM)
	(IN FREE AIR AT RATED VOLTAGE)
STATIC AIR PRESSURE	: 0.242 InH ₂ O (min. 0.196 InH ₂ O)
STATIC AIR PRESSURE	: 6.16 mmH ₂ O (min.: 4.989 mmH ₂ O)
	(IN FREE AIR AT RATED VOLTAGE)
NOISE LEVEL	: 35.0 dB(A) (MAX.: 38.0 dB(A))
LIFE EXPECTANCY	: 50000 Hours at 40°C / 65% RH
NET WEIGHT	: 11 Gram

The standard of JARO Thermal's fan relative humidity is 65%, and the temperature is 25°C for the standard testing. If you have any question, Plesae refer to environmental condition on 5-0 first. Other special request Plesae contact JARO Thermal for spec checking.



SPECIFICATION

JARO MODELJED0401012US1A0T(8P5AR)-X(2190)


1	-0	М	ΙΔ٦	ΓΕΡ	Δ 15	ı

- 1-1 Frame Material PBT OF UL94 V-0
- 1-2 Fan Blade Material PBT OF UL94 V-0
- 1-3 Other material See 8.0 Dimension Drawing
- 1-4 Environmental Standard
 - [V] RoHS
 - [V] REACH
 - [] Halogen Free

2-0 FAN VOLTAGE CURRENT, LOCK ROTOR, AIR FLOW, STATIC PRESSURE & NOISE DEFINITION

- 2-1 Start Voltage By sudden switching ON fan is start to rotate.
- 2-2 Input Power Input Power shall be measured after 3 minutes for continuing rotation by rated voltage.
- 2-3 Rated Current Rated Current shall be measured after 3 minutes by continuing rotation by rated voltage.
- 2-4 Rated Speed Rated Speed shall be measured after 3 minutes for continuing rotation by rated voltage.
- 2-5 Locked Rotor Current: Locked current shall be measured within one minute of rotor locked, after 3 minutes by continuing rotation at rated voltage in clean air.
- 2-6 Air Flow & Static Pressure: The air flow data and static pressures should be determined in accordance with AMCA-210 standard or DIN24163 specification in chamber testing and record the test record.
- 2-7 Noise Level: The measurement of noise level is carried out with reference to CNS8753 in an anechoic chamber with the microphone positioned 1 meter from the air intake. Testing fan shall be hung in clean air.

Noise Level Measure





JARO MODELIED0401012US1A0T(8P5AR)-X(2190)

3-0 FAN FUNCTION DEFINITION

- 3-1 Rotation Direction Counterclockwise from impeller side.
- 3-2 Lock Rotor Condition

No damage for winding or electronic in locked rotor condition. And no damage after 72hrs continuing for lock rotor condition.

3-3 Auto Restart

Fan will automatic restart without any abnormal usage.

3-4 Dead Angle

Switch the fan change from off to on condition. Restart the fan, it will automatic restart by fan power on.

3-5 Polarity

Check the voltage and polarity before turn on the power to the fan.

3-6 Insulation Resistance

Do not use < 10M ohm between housing and positive end of lead wire (red) at 500V DC.

3-7 Dielectric Strength

No damage should be found at 500 VAC for 60 seconds, measured with 1mA trip current between housing and positive end of lead wire.

4-0 FAN PACKAGE TEST

4-1 Free Drop Shock

Base on Jaro Thermal's standard package, the fan package will test and drops on any three faces - Test standard is 30cm height. The base is wood board for 10mm thick.

5-0 FAN ENVIRONMENTAL CONDITION

- 5-1 Operating Temperature / Humidity
 - -10°C to +70°C at humidity 5% to 90% Relative humidity.
- 5-2 Humidity

After 96 hours, 95% RH, 40+/-2°C per MIL-STD-202F, method 103B humidity test, the measured data on insulation resistance and dielectric strength shall meet the specification.

5-3 Storage Temperature

All function shall be normal after 500 hours storage at -20°C to +75 °C with a 24 hour recovery period at room temperature. Humidity 5% to 95% Relative humidity

5-4 Do not store this fan in an environment with high humidity. This fan must be stored in accordance with the storage temperature. Do not store the fan for over 6 months; If this fan is stored for more than 6 months, JARO THERMAL recommends functional testing before using.



JARO MODELIED0401012US1A0T(8P5AR)-X(2190)

5-5 Improper way to disassembled fan will cause the fan get into dust or dip into water. Which will in defects is not covered in the warranty. Do not use the fan in the environment with corrosive air or liquid.

6-0 MASS PRODUCTION SAMPLE PLAN INSPECTION

All fans shall meet the quality inspection under MIL-STD-105E standard list as follow:

Critical 0.25%

Major 1.00%

Minor 2.50%


7-0 FAN USE WITH CAUTION

- 7-1 Please do not stick a grease and/or an oil to the fan housing or blade which may have a harmful influence by a chemical reaction at high humidity.
- 7-2 If the fan is reinstalled, please pay special attention to the noise due to the vibration (or resonance).
- 7-3 During the testing of the fan, please make sure the finger guard is use for your safety.
- 7-4 While the fan is running, please do not lock the fan intentionally for a long time. This will cause overheating by long period locking status. This action will damage the fan.
- 7-5 Please do not touch and push Fan Blade with fingers or others, fan blade and ball bearings may be damaged and it causes noise defect.
- 7-6 Do not carry the fan by its lead wires.
- 7-7 If the fan does not have the polarity protection function, the connection of the colored wires should be red + red, and black + black, or else the fan will be damaged in no time.
- 7-8 For the models without reverse connection of polarity protection, please do not connect the lead wire in reverse position.
- 7-9 Please don't install this fan in series with 2x voltage inputs. For example, if a single fan rated at 12V, then don't install two of them in series with 24V input.
- 7-10 Every specific fan is designed for its certain application (project). Therefore, if you want to use this fan in other application (project), please inform JARO first so that we can confirm whether there is any issue which might be incurred from the reason of this different application (project) or not.
- 7-11 The "Life Expectancy" of this fan has not been evaluated for use in combination with any end application. Therefore, the Life Expectancy in the Test Reports(L10 and MTTF Report) that relate to this fan is for reference only and shall not construe any kind of warranty of JARO to the life of any specific fan, either expressed or implied.
- 7-12 The period of product warranty, unless otherwise agreed by JARO in written, shall be 12 months staring from the date of production.



DIMENSION DRAWING

JARO MODEUED0401012US1A0T(8P5AR)-X(2190)




Safety: CE



LABEL DRAWING

JARO MODEUED0401012US1A0T(8P5AR)-X(2190)

Label Drawing




Label Material	Background color
PET	Silver



PERFORMANCE CURVE

JARO MODEUED0401012US1A0T(8P5AR)-X(2190)

9-0 PERFORMANCE CURVE





LIFE EXPECTANCY


JARO MODEUED0401012US1A0T(8P5AR)-X(2190)

10-0 LIFE EXPECTANCY

故障定義	試驗結果:包含故障時間、數據、統計、・・・等
Product Specification & Faiure Definiton	Test Result: Including Time Of Failure . Datum . Statistics ect.
1.風扇不轉 (Fan Not Work)	・溫度加速因子 TEMP A.F = e $(\Delta H/K) \times (\frac{1}{273+Tl} - \frac{1}{273+Th})$
2.轉速超出規格30% (Speed Over 30% Origin)	・總試驗時間 Total Test Time = 200000 HRS.
3.電流超出規格30% (Current Over 30% Origin)	・査表得 (MTTF By GEM Table) MTTF = 153620 HRS.
	・溫度 / TEMP. / MTTF / L10
1.性能測試時點 The Time Of Check Point	温度 信賴水準90% L10 CONFIDENCE LEVEL
Start: 0Hr, 500Hrs, 1000Hrs And Finshed	30 ℃ 1065201 112126
	40 °C 536033 56424
	50 °C 281461 29627
	60 °C 153620 16171
	70 °C 86858 9143

2.Herewith, we could assume as right on the basis of above test result. Besides, if the actual test time exceed the required, it comes out that those fans' L₁₀ expectancy and MTTF are greater than the warrant.

MTTF: Mean Time To Failures. It should be used in a non-reqairable system setting. Now we show the MTTF in our life report, that's because we will not repair the failed fans during life experiment. MTBF: Mean Time Between Failures. It should be used in a repairable system setting. Basically, MTBF is equal to MTTF, they use same formula to work out a life data.






APPLICATION NOTE

JARO MODELIED0401012US1A0T(8P5AR)-X(2190)

NOTICE FOR OPERATION









- 1. Hold the fan by frame side. Do not hold lead wires.(Fig.1)
- 2. Do not touch or press on the impeller. Do not crush the frame. (Fig.2)
- 3. Do not drop the fan on the ground. Hit the frame may cause the fan damaged. (Fig.3)
- 4. Connect the power cord properly and apply voltage according to specification. (Fig.4)

NOTICE FOR ASSEMBLY AND AMBIENT CONDITIONS

- When applying our fan your device, please check thoroughly any variation of EMC, temperature rise, life data, quality, etc. of this product by shock/drop/vibration testing, etc. If there is any problem or accident in connection with this product, it should be mutually discussed and checked by both parties.
- 2. Take proper care for handling this fan. Components such as fan holders or bearings may be damaged by fingers touch or other objects. Additionally, static electricity (ESD) may damage the internal circuits of the fan.
- 3. DO NOT operate this fan in proximity to hazardous materials such as organic silicon, cyanogen, formalin, phenol, or corrosive gas environments. Any hazardous materials flow to the fan side may cause damaged or malfunction.
- 4. JARO recommends that you protect this fan from exposure to outside elements such as dust, condensation, humidity or insects.
 - Exposure of this fan to outside elements such as dust, condensation, humidity or insects may affect its performance and may cause safety hazards. JARO does not guarantee the damage to the product caused by outside elements.
- 5. This fan must be installed properly and securely. Improper mounting may cause harsh resonance, vibration, and noise. If you have any question about fan mounting, please discuss with JARO if you are not sure the correct mounting method.
- 6. DO NOT use or store the fan with higher humidity and temperature specified in spec. The fan must be stored with the attached specifications regarding storage temperature. If this fan is stored for more than 6 months, JARO recommends to perform functional testing before using. Please contact JARO if you are not sure how to perform functional test
- 7. The "Life Expectancy" of this fan has not been evaluated for use in combination with any end application. Therefore, the Life Expectancy Test Reports (L10 and MTTF Report) that relate to this fan are only for reference.
- 8. Fan guards may prevent injury during handling or installation of the fan.